



## **SeaRescue Tactical TS Back Zip**

Reference# 85522-121590M

## **SeaRescue Tactical TS**

This super slim suit is designed for demanding operations within rescue services and first responders/special forces in the military and police. The telescopic construction offers extreme flexibility with regards to freedom of movement, comfort and sizing.

The suit is a result of a long development process and testing in partnership with users in the target groups mentioned above.

### **Facts**

- A new construction based on HP's unique basic design for improved freedom of movement
- The suit is engineered with a narrower basic pattern to avoid excess fabric around your body
- To further improve freedom of movement, the waist is equipped with a unique telescopic construction. This solution provides improved freedom of movement, and also a unique flexibility in terms of sizes. A medium size suit may fit persons ranging from 175cm to 195cm in height.
- The telescopic solution is adjusted to fit your height with the internal elastic braces.
- As standard manufactured in our unique 3-ply Aramid laminate for the best FR protection, breathability and longevity
- Neck seal in latex and cuffs in neoprene glide skin
- Waterproof main entry zipper on the back
- Relief zipper in front
- MOLLE on both sides of the upper chest for mounting of optional communication equipment
- Astra patches on the chest for attachment of e.g. ID
- Unique seat construction without seams eliminates wear points and improves mobility

## Product Detail

|                                                              |                                                                                                                                                          |
|--------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Area of application</b>                                   | <i>Civil Service/ Rescue Services/ Armed Forces</i>                                                                                                      |
| <b>Type of suit</b>                                          | <i>Special suit<br/>Work suit</i>                                                                                                                        |
| <b>Material</b>                                              | <i>HP Aramid 3L</i>                                                                                                                                      |
| <b>Adjustments</b>                                           | <i>Waist adjustment</i>                                                                                                                                  |
| <b>Main zipper type</b>                                      | <i>PU/Plastic, closed<br/>Soft PU/plastic with teeth, closed - 1 zipper puller</i>                                                                       |
| <b>Neck seal</b>                                             | <i>Latex</i>                                                                                                                                             |
| <b>Wrist seals</b>                                           | <i>Neoprene</i>                                                                                                                                          |
| <b>Fit / Ergonomics</b>                                      | <i>Articulated knees, seat and elbows<br/>Ergonomic<br/>Sleeves constructed in Y-shape for mobility<br/>Slim<br/>Telescopic in waist for flexibility</i> |
| <b>Colour</b>                                                | <i>Black</i>                                                                                                                                             |
| <b>Hood</b>                                                  | <i>Detachable, in neoprene</i>                                                                                                                           |
| <b>Gloves</b>                                                | <i>5-finger neoprene in sleeve pocket</i>                                                                                                                |
| <b>Boots / socks</b>                                         | <i>Socks</i>                                                                                                                                             |
| <b>Reinforcement knee</b>                                    | <i>Additional layer of reinforcement material</i>                                                                                                        |
| <b>Braces (elastic adjustable)</b>                           | <i>Yes</i>                                                                                                                                               |
| <b>Thermal protection without lining/inherent insulation</b> | <i>1.5 hours (ISO 2002 Class C less than 5°C watertemp)</i>                                                                                              |
| <b>Service interval (standard)</b>                           | <i>When needed</i>                                                                                                                                       |
| <b>Seat construction</b>                                     | <i>Without seam - eliminated wear point</i>                                                                                                              |
| <b>Orientation of main zipper</b>                            | <i>Back zip</i>                                                                                                                                          |
| <b>Relief zipper</b>                                         | <i>Yes</i>                                                                                                                                               |

Contact us

Hansen Protection AS, PB. 218, N-1501 Moss  
Tel. +47 69 00 13 00, e-post: [hpro@hansenprotection.no](mailto:hpro@hansenprotection.no)